



NOTES:

1. IF SEAMS RUN WITHIN 18" (457mm) OF DRAIN, INSTALL A MIN. 4' X 4' (1.2m x 1.2m) ULTRAPLY TPO PATCH ON TOP OF MEMBRANE ASSURING SEAM IS COVERED, OR STRIP IN SEAM WITH 6" (152.4mm) WIDE ULTRAPLY TPO MEMBRANE.
2. TAPERED INSULATION WITH APPROPRIATE BONDING SURFACE SHALL BE USED.
3. IN REROOF APPLICATIONS:
 - REMOVE EXISTING FLASHINGS DOWN TO METAL SUMP.
 - REPAIR OR REPLACE BROKEN CLAMPING RING.
 - DRILL AND TAP BROKEN DRAIN BOLTS AND REPLACE.
4. 20 YEAR WARRANTY SYSTEMS REQUIRE THAT THERE BE TWO LAYERS OF 0.060" MEMBRANE LINING THE SUMP OR 4' x 4' AREA AROUND THE DRAIN, SECOND MEMBRANE NOT SHOWN IN THIS DETAIL.