TECHNICAL INFORMATION BULLETIN

TO: FIRESTONE CUSTOMERS **JULY 9, 2012**
FIRESTONE SALES AND TECHNICAL REPRESENTATIVES

RE: ULTRAFLASH PRIMER ALTERNATIVE

Due to current environmental regulations, UltraFlash Primer (W70UFPR003) cannot be used in states regulated by the Ozone Transport Commission (OTC) states (Connecticut, Delaware, the District of Columbia, Maine, Maryland, Massachusetts, New Hampshire, New Jersey, New York, Pennsylvania, Rhode Island, Vermont, and Virginia) or in California. The reason for this is that the primer exceeds the maximum allowed VOC content of 250 g/L dictated in those areas.

Until a compliant primer is available for UltraFlash Liquid Flashing, please use the following technique when flashing roof top metal details.

1. Remove any existing flashing material from the object to be flashed.
2. Wipe the entire surface of the object to be flashed with Acetone using a clean rag.
3. Roughen the surface of the object to be flashed using a wire brush.
4. Flash the detail in accordance with the Firestone UltraFlash Flashing Application Guide found on the Firestone website.
5. Keep all adhesives, sealants and cleaning materials away from ALL ignition sources (i.e., flames, fire, sparks, etc.). Do not smoke while using these materials.
6. Consult container labels and Material Safety Data Sheets (MSDS) for specific safety instructions for all products used on the project.
7. Follow all OSHA, state, local and national safety practices.

Please contact your Roof Systems Advisor at 1-800-428-4511 (option 1) or your Firestone Sales Representatives with any questions or concerns.

This is just another example of Firestone proving that “Nobody Covers You Better.”

Carter C. Slusher
Modified Bitumen/Polyiso Systems Engineer